

Rear suspension change 101

1. Jack up the car. You can either do side by side or bite the bullet and jack up both sides.



2. Drop the back seats down. If you look at the top of the side bolster on the inside face is a 10mm head bolt. Remove this to allow the bolster to be pulled forward.



3. Once the bolster is free to move you need to release the two plastic pegs which hold the black carpet trim in position.



You can now move the trim to the side and remove it completely.

4. You should now see this.

