

11. Now get out your spring compressors and compress the suspension spring. You need to compress it quite some way, as you can see I squeezed 5-6 coils. This gives you enough room to push the strut down so the centre shaft will clear the body work and swing out into the wheel arch.



12. Now remove the bottom pin, the 21mm head one and lift out the suspension strut.

