



Gently tap solenoid parts back into place until flush



You can now depress plunger and notice one hell of a difference. at this point you will have to clean the body of the valve in some form of cleaner.



Spray some more grease etc into the 3mm hole



Finally reassemble and refit to vehicle, trust me you will be very impressed with the results.